

In-Drawer Power Point

Installation Instructions

INSTRUCTIONS

- 1/ Cut slot in back panel of drawer box measuring 106W x 40H x R20 (as specified in Figure A).
- 2/ Pull plug and cord through the front of the slot and fit main housing of power point into the slot with the back of the face plate flush with the board.
- 3/ Screw into the board through the holes on either side of the face plate to secure powerpoint (see Figure B).

ELECTRICAL INFORMATION

Input: 220~240V ac 50/60Hz

Output: USB-C + USB-A 5V/3A

USB-C: 5V3A / 9V2A / 12V1.67A (20W Max)

USB-C: 5V3A / 9V2A / 12V1.5A (20W Max)

Typc-C + USB-A: 5V/3A Max:20W



WARNING

To reduce the risk of fire, electric shock, or injury:

- 1/ Use the unit indoors only.
- 2/ Do not use extension cord(s) to connect the unit.
- 3/ Do not use product for connecting devices over 7.5A.
- 4/ Do not try to open unit for any reason.

Figure A.




Figure B.

